


W9TH WORKBENCH  
TOP FRAME  
11 / 2020


- NOTES:
1. ALL DIMENSIONS ARE INCH
  2. FRAME BUILT WITH STANDARD 2x4
  3. DEPTH "D" CAN BE SCALED TO FIT YOUR NEEDS
  4. FRAME BUILT WITH 10x3 CABINET INSTALLATION SCREWS
  5. USE 1/4 x 4 LAG SCREWS - ATTACH TO STUD IN WALL - L1, L2, L3, L4



W9TH WORK-BENCH  
TOP DETAIL  
11 / 2020


NOTES:

1. 3/4 PLYWOOD
2. ATTACH TO TOP FRAME WITH DRYWALL SCREWS
3. COVER PLYWOOD WITH 1/4 MASONITE HARD BOARD (SAME SIZE)  
\* DO NOT SCREW OR GLUE - THIS IS A REPLACABLE BENCH TOP
4. HOLD MASONITE IN PLACE WITH 1 INCH ANGLE ALUMINUM SCREWED TO 3/4 PLYWOOD ON SIDES



W9TH WORKBENCH  
LEG DETAIL  
11 / 2020

- NOTES:
1. ALL DIMENSIONS ARE INCH
  2. BUILT WITH STANDARD 2X4
  3. BUILT WITH 10X3 CABINET INSTALLATION SCREWS
  4. ALL LEGS IDENTICAL



NOTES:

1. ALL DIMENSIONS ARE INCH
2. BUILT WITH STANDARD 2X4
3. BUILT WITH 10X3 CABINET INSTALLATION SCREWS
4. COVER SHELF WITH 3/4 PLYWOOD AND MASDNITE - SAME AS TOP OF BENCH - TRIM WITH 1 INCH ANGLE ALUMINUM

WATH WORK BENCH  
 BOTTOM SHELF FRAME  
 11 / 2020